




OWNER'S MANUAL



GETTING STARTED



The BBE Free Fuzz is a vintage style Fuzz Pedal that responds dynamically to a player's subtle volume and picking style while retaining the over-all tonal characteristics of the instrument. The Free Fuzz adds rich harmonics and excellent over-tones to your amp and are easily controlled with adjustments to the volume and tone controls on your instrument.

FEATURES

- Class A Vintage Fuzz Circuit
- Matched Silicon Transistors
- True hard-wire bypass
- Blue LED status indicator
- 5-Year Warranty

CONTROLS

Volume- Adjusts the Output level


Fuzz- Adjusts the amount of Fuzz/Gain

SIGNAL CHAIN PLACEMENT


The Free Fuzz should be placed early in the signal chain. Typically 1st.

SAMPLE SETTINGS


CHUNK FUZZ




SPIRIT IN THE SKY / N GREENBAUN



JIMI



SMASHING PUMPKINS / CHERUB ROCK



POWER REQUIREMENTS

The Free Fuzz can be powered by a single 9V Battery or an external DC power supply. The polarity of the external power supply must be Center Negative, Outer Sleeve Positive. Please disconnect your instrument cable from the pedal's input jack to preserve battery life when not in use.

SPECIFICATIONS

Input Impedance.....	100K Ω	Current Draw @ 9vdc.....	3.5ma
Output Impedance.....	1K Ω	Bypass.....	True Hard Wire
Signal to Noise.....	>90dB	Dimensions.....	3.7"w, 4.7"d, 1.8"h
THD @ 1kHz.....	0.1%	Weight.....	1 lb.

WARRANTY

Five Years



BBE Sound, Inc.
Huntington Beach, California 92649
TEL: 714.897.6766 FAX: 714.896.0736
bbesound.com

REV. 08/10